




30" FREESTANDING ELECTRIC RANGE

MODELS:

WFE505W0HB0 (Black)
WFE505W0HW0 (White)
WFE505W0HS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	10	7101P485-60	Screw, Anti-Tip Kit
	W11102911	Guide, Use and Care		W11034825	Black	11	3196169	Screw
	W10403811	Instructions, Installation		W11034824	White	12	W10691223	Pan, Radiant Element
	W11102742	Diagram, Wiring	5	W10275048	Element (3000/1400W)			FOLLOWING PARTS NOT ILLUSTRATED
	W11102747	Sheet, Tech			(Left Front)		W11028533	Harness, Main
	9762761	Tips, Safe Cooking (English)	6	8273994	Element (1200W) (Left Rear and Right Rear)		3391018	Tie, Cable
2	W10225448	Spring, Element	7	8273992	Element (2500W) (Right Front)		W10848522	Harness, Cooktop (Right)
3	W10607641	Bracket, Cooktop (Left)			(Right Front)		W10848523	Harness, Cooktop (Left)
	W10607642	Bracket, Cooktop (Right)	8	W10799048	Element, Warm Zone (Center)		W10174460	Harness, Warm Zone
			9	W10306542	Bracket, Anti-Tip			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10434452	Switch, Infinite (Dual)	7		Knob
	W10184437	Black (Left)			(Left Front)		W11022718	Black
	W10184438	Black (Right)		3148951	Switch, Infinite		W11022720	White
	W10184433	White (Left)			(Left Rear and Right	8	W10134247	Shield, Heat
	W10184434	White (Right)			Rear)	9	3400882	Screw
2	W10695491	Bracket, Control		3148954	Switch, Infinite	10	8272473	Cover, Upper Rear
3		Console, Assembly			(Right Front)	11	W10525121	Bracket, Console
	W11027374	Black	5	3196178	Screw			Mounting
	W11027375	White	6		Electronic, Control			
	W11027373	Stainless			(LCX)			
				W11038140	Black			
				W11038142	White			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390007	Assembly, Base Rail (Right)	28	3196169	Screw
2	3196154	Screw				29	W10326122	Cover, Terminal Block
3		Panel, Side		W10390008	Assembly, Base Rail (Left)	30	W10031780	Screw
	W10162245	Black				31	W10268578	Rack, Oven
	W10575396	White	16	W10058460	Foot, Leveling	32	W10910404	Counterweight
4	3400029	Nut	17	3196548	Fuse, Thermal	33	W11034869	Screw
5	W10129032	Seal, Door	18	3196172	Screw	34	9761301	Screen, Vent
6	9757340	Element, Broil	19	W10404688	Clip, Oven Support	35	W10281322	Kit, Bare Wire Adapter Block
7	W11111743	Element, Bake	20	3186034	Bracket, Service			FOLLOWING PARTS NOT ILLUSTRATED
8	3196174	Screw	21	W10245259	Block, Terminal			
9	W10134285	Tube, Vent	22		Back, Main (Not Serviced)		8273263	Insulation, Wrap
10	W10674705	Glide, Drawer Front					8272611	Insulation, Back
11	W10341186	Assembly, Front Foot	23	3196178	Screw		W10333344	Insulation, Flue
12	W10067840	Screw	24	W10454648	Assembly, Light			
13	8054068	Retainer, Insulation	25	311255	Bulb, Oven Light			
14	W10137382	Clip, Panel	26	3400016	Screw			
			27	W10181986	Sensor, Oven			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Vent	9		Glass Assembly, Outer Door	18		Trim, Lower Door
	W10310922	Black					8523177	Black
	W10310920	White		W10851726	Stainless		8523175	White
2	W10480830	Screw	10		Trim, Side	19		Glass Assembly, Outer Door
3		Handle, Door		W10746436	Black (Left)			
	W11022643	Black		W10746435	Black (Right)		W10884159	Black
	W11022644	White		8523172	White (Left)		W10409945	White
	W10875206	Stainless		8523166	White (Right)			
4	9761344	Liner, Door	11	W10327235	Screw			
5	W10031790	Screw	12	W10299227	Hinge, Door (Passive)			
6	W10620754	Glass, Inner	13	W10031780	Screw			
7	9761505	Retainer, Insulation	14	W10544179	Strap, Door			
8	W10299225	Hinge, Active	15	W10200660	Screw			
		(Black and White Models)	16	W10884775	Nameplate			
	W10299226	Hinge, Active	17		Standoff, Handle			
		(Stainless Model)		W11037027	Black			
				W11037028	White			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	6		Panel, Drawer Front	8		Rivet, Push
	W10330070	Stainless		8053341	Black		3196813	Black
2	W10688022	Drawer, Storage		8053339	White		3196814	White
3	W10462910	Bracket, Mounting Drawer	7	W10462912	Bracket, Mounting Drawer	9	3196169	Screw
		(Stainless Model)			(Black and White Models)			
4	W10674708	Glide, Drawer Rear						
5	3196165	Screw						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	3191048	Glass Cleaner
	4396923	Grid, Broiler Pan and
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10355010	Cleaner, Kitchen & Appliance
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	4396096RB	Griddle
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting