


Installation Guide

5 & 7 Series Accessory Knob Kits



SSKKVGR53036	Stainless Knob Kit - 5 Series Gas Range/Rangetops 30/36"
SSKKVGR54860	Stainless Knob Kit - 5 Series Gas Range/Rangetops 48/60"
SSKKVDR53036	Stainless Knob Kit - 5 Series Dual Fuel Ranges 30/36"
SSKKVDR54860	Stainless Knob Kit - 5 Series Dual Fuel Ranges 48/60"
SSKKVIR530	Stainless Knob Kit - 5 Series Induction / Electric Ranges 30/36"
SSKKVDOF	Stainless Knob Kit - 5 Series Wall Ovens
BCKKVDOF	Black Chrome Knob Kit - 5 Series Wall Ovens
BCKKVGR736	Black Chrome Knob Kit - 7 Series Gas Range/Rangetops 36"
BCKKVGR748	Black Chrome Knob Kit - 7 Series Gas Range/Rangetops 48"
BCKKVDR736	Black Chrome Knob Kit - 7 Series Dual Fuel Ranges 36"
BCKKVDR748	Black Chrome Knob Kit - 7 Series Dual Fuel Ranges 48"

Parts Included in Kits

SSKKVGR53036

Part		QTY
035881-000	Top Burner Knob	6
035891-000	Oven Thermostat Knob	1
035883-000	Griddle Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

SSKKVDR53036

Part		QTY
035881-000	Top Burner Knob	6
035883-000	Griddle Knob	1
035893-000	Oven Thermostat Knob	1
035895-000	Oven Selector Knob	2
065005-000	5 & 7 Series Knob Kit Install	1

SSKKVIR530

Part		QTY
035904-000	Induction Burner Knob	4
035897-000	Electric Burner Knob	2
035904-000	Electric Burner Knob	2
035893-000	Oven Thermostat Knob	1
035895-000	Oven Selector Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

SSKKVDOF

Part		QTY
036330-000	WO Oven Knob	4
065005-000	5 & 7 Series Knob Kit Install	1

BCKKVGR736

Part		QTY
061041-000	Top Burner Knob	6
067118-2544	Oven Thermostat Knob	1
067119-2617	Griddle / 18" Oven thermostat Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

BCKKVDR736

Part		QTY
061041-000	Top Burner Knob	6
067119-2617	Griddle Knob	1
061043-000	Oven Thermostat Knob	1
061044-000	Oven Selector Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

SSKKVGR54860

Part		QTY
035881-000	Top Burner Knob	8
035891-000	Oven Thermostat Knob	2
035883-000	Griddle / 18" Oven thermostat Knob	2
035885-000	Grill Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

SSKKVDR54860

Part		QTY
035881-000	Top Burner Knob	8
035883-000	Griddle / 18" Oven thermostat Knob	2
035885-000	Grill Knob	1
035893-000	Oven Thermostat Knob	2
035895-000	Oven Selector Knob	2
035898-000	18" Oven Selector Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

BCKKVDOF

Part		QTY
064101-2095	Black Chrome WO Oven Knob	4
065005-000	5 Series Knob Kit Install	1

BCKKVGR748


Part		QTY
061041-000	Top Burner Knob	8
067119-2617	Griddle Knob	1
067118-2544	Oven Thermostat Knob	1
067117-2549	18" Oven Thermostat Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

BCKKVDR748


Part		QTY
061041-000	Top Burner Knob	8
067119-2617	Griddle Knob	1
061029-000	Oven Thermostat Knob	2
061038-000	Oven Selector Knob	1
061039-000	18" Oven Selector Knob	1
065005-000	5 & 7 Series Knob Kit Install	1

Removing Knobs / Installing Knobs

1. Begin by removing the knobs from the kit. Sort the knobs according to knob type based on their graphics – i.e. surface burner knobs, oven control knobs, griddle, grill, if applicable.




2. Before removing the current knobs, line up the new knobs from the kit across the top of the landing ledge of range or rangetop. Match the graphics of the new knobs with the graphics of the current knobs. In most cases, all knobs will not be used. This will help eliminate confusion and will help to assure the knobs are replaced correctly.




MAKE SURE KNOBS POINT TO THE "OFF" POSITION BEFORE REMOVING.

3. **Important** - When removing the knobs from the product, grip the knob securely and pull straight back. It is important to pull the knob straight back so as not to break or bend the valve stem.



4. **Important** - In almost all installation cases there should be extra knobs after all knobs have been changed out on the product. It is recommended to keep these extra knobs in the event that one is needed at a later date.



Viking Range, LLC
111 Front Street
Greenwood, Mississippi 38930
(662) 455-1200

For product information, call 1-888-845-4641
or visit our web site at vikingrange.com in the US